

Alcatel-Lucent OmniPCX Enterprise

Communication Server

Functions and corresponding codes

If your telephone has neither the icon nor the corresponding key, the function is activated by entering the code.

| Function | Code |
|-------------------------------------|------|
| 3 party conference call | 3 |
| Associate call | |
| Attendant call | *9 |
| Broker call | 1 |
| Business account code | *0 |
| Business account code prefix | |
| Call announcement | 8 |
| Call back request | 5 |
| Call from personal directory | |
| Camp on | |
| Camp on control | 6 |
| Cancel follow me | |
| Cancel overflow | |
| Cancel remote forward | *65 |
| Cancel wake-up/appointment reminder | *81 |
| Change associate number | #01 |
| Charging meter readout | #3 |
| Common hold | **0 |
| Consult call back request | *68 |
| Consult call on hold | *74 |
| Consult voice mail | *** |
| Contrast programming | *67 |
| Direct call pickup | *72 |
| Direct outside line | 9 |
| Direct paging call | *86 |
| Do not disturb | *78 |
| DTMF end to end dialing | #4 |
| Enquiry call/Enquiry off | 2 |
| Forward cancellation | *64 |
| Forward on busy or no reply | *63 |
| Forward on no reply | *62 |
| Group call pickup | *73 |
| Identity display | **2 |
| Immediate forward | *60 |
| Immediate forward on busy | *61 |
| Immediate overflow on busy | |
| Intrusion | 4 |

Alcatel-Lucent Enterprise in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice.

Alcatel-Lucent OmniPCX Enterprise

Communication Server

| Function | Code |
|---|------|
| Language | *84 |
| Last caller call back | *69 |
| Malicious call | |
| Meet me conference | **6 |
| Night service answering | #8 |
| Overflow on no reply | *66 |
| Overflow on no reply and immediate overflow on busy | |
| Padlock | *77 |
| Paging reply | |
| Paging request | |
| Park call/retrieve | *75 |
| Password modification | **4 |
| Personal directory programming | #5 |
| Private call | |
| Protection against beeps | *87 |
| Redial last number | *70 |
| Remote forward | *88 |
| Secret identity | **3 |
| Select principal line | *82 |
| Select secondary line | *83 |
| Set group entry | **7 |
| Set group exit | **8 |
| Substitution | *76 |
| Voice mail | ## |
| Voice mail direct access | |
| Wake-up/appointment reminder | *80 |

Name:

Telephone No: